#### **Teknatool International Limited**

7D Dallan Place, Rosedale, Auckland, New Zealand Tel: +64 09 477 5600 Fax: +64 477 5601

Email: <a href="mailto:service@teknatool.com">service@teknatool.com</a>
Website: <a href="mailto:www.teknatool.com">www.teknatool.com</a>



# Frequently Asked Questions

# Galaxi DVR 1644 Wood Lathe General Questions

Date Raised: 9 February 2017

Safe practices should always be employed to ensure the Health and Safety of yourself, employees and customers (if applicable) Refer to product manuals, exploded drawings and our website if further assistance is required, or contact us on service@teknatool.com

**Date Amended** 

Question: What are the dimensions and weight of the lathe?

### **Assembled**

## **Dimension**

1875mm(L) x 495mm(W) x 1260mm (H) 73.8"(L) x 19.5"(W) x 49.6"(H)

#### Weight

204kg (450 lb)

# **Shipping**

# **Dimension**

1740mm(L) x 550mm(W) x 560mm(H) 68.5"(L) x 21.7"(W) x 22.0"(H)

## Weight

238Kg (524.7 lb)

## Question: Can I buy the Galaxi without the legs/ stands?

No. The Galaxi DVR lathe has to be purchased along with the legs.