

Teknatool International Limited

7D Dallan Place, Rosedale, Auckland, New Zealand

Tel: +64 09 477 5600

Fax: +64 477 5601

Email: service@teknatool.com

Website: www.teknatool.com





Frequently Asked Questions

Date Raised: 11/11/2020

Date Amended:

Safe practices should always be employed to ensure the Health and Safety of yourself, employees and customers (if applicable) Refer to product manuals, exploded drawings and our website if further assistance is required, or contact us on service@teknatool.com

How to Enter Service Mode on DVR Orion 1844 Lathe

1	Turn on your Galaxi and hold down the <F/R> key then press the <F2> key.	
2	<p>Enter the service password "3210" by pressing:</p> <p><F1>: 3 times <F2>: 2 times <F3>: 1 time</p> <p>Then press <ON> to activate service mode.</p>	

You are now in Service Mode!

There will be a "Service" option in the 3rd page of the MENU if you were successful.

To perform a factory reset:

Hold down the <F3> key and then press <OFF>. When prompted with the factory reset screen, turn the lathe off. Wait for the machine to completely shut down before turning it back on.